

I311(X)A Compact Rugged Isolator/ Circulator, 406-512 MHz

- Temperature compensated
- · Low insertion loss, high isolation
- · Reliable design with top quality sub-components
- · Each unit is optimized to customer specified frequency

Sinclair's 'I3' series isolators and circulators offer superior performance in a compact rugged package. Careful temperature compensation and top quality components ensure high isolation with very low insertion loss over their full operating temperature range, and offer a high degree of RF and magnetic stability.

Threaded holes in the steel casing allow surface mounting to any non-magnetic material. Aluminum brackets can also be supplied to isolate the unit from the mounting surface to increase stability.

Circulators are supplied without loads. Isolators come equipped with a variety of load terminations.

Please specify the Tx frequency and load requirement at time of order, or contact your Sinclair Sales Representative or Customer Service Representative for assistance and detailed info.

- X Load
- 0 No load
- 2 30 watt
- 3 60 watt



I3112A 30 watt model shown.

Region	United States	Europe, Middle East and Africa	Caribbean and Latin America	Canada and rest of the world
Telephone	USA: 1 800 263 3275	International: +44 (0) 1487 84 28 19	International: +1 905 726 7676	Canada: 1 800 263 3275 International: +1 905 727 0165
E-mail	salesusa@sinctech.com	salesuk@sinctech.com	salesla@sinctech.com	salescan@sinctech.com
Product Specification Sheet EPR 018803		I311(X)A	Issue: 2	Dated: 26-01-16 Dated: 30-03-15



MHz	406 to 512	
MHz	12	
	No	
	1.25:1	
dB	35	
	N-Female	
W	125	
dB	0.3	
dB	0.5	
dB	25	
	MHz dB W dB dB dB	MHz 12 No 1.25:1 dB 35 No-Female N-Female W 125 dB 0.3 dB 0.5

Mechanical Specifications

Electrical Creations

Width	in (mm)	2.5 (64)	
Depth	in (mm)	1.4 (36)	
Length/ Height	in (mm)	2.5 (64)	
Weight	lbs (kg)	1.1 (0.5)	
Actual shipping weight	lbs (kg)	2 (0.91)	
Shipping dimensions	in (mm)	13x9x3 (330x229x76)	

Ordering Information

Height, width, depth and weight excludes connectors and loads.

Specify Tx frequency and load at time of order.

Environmental Specifications

Temperature	range
-------------	-------

°F (°C)

-22 to +140 (-30 to +60)

Region	United States	Europe, Middle East and Africa	Caribbean and Latin America	Canada and rest of the world	
Telephone	USA: 1 800 263 3275	International: +44 (0) 1487 84 28 19	International: +1 905 726 7676	Canada: 1 800 263 3275 International: +1 905 727 0165	
E-mail	salesusa@sinctech.com	salesuk@sinctech.com	salesla@sinctech.com	salescan@sinctech.com	
Product Specification Sheet EPR 018803		I311(X)A	Issue: 2	Dated: 26-01-16 Dated: 30-03-15	
Cincleide commitment to readuct leadership may read this improvement or shapes to this readuct					

Sinclair's commitment to product leadership may result in improvement or change to this product Copyright © Sinclair Technologies