

Intermod Supression Panels Low Band, Aviation, and VHF IM Suppression Pannels PC2 Series

PC2214 I.M. Suppression panel, rack mount, dual stage isolator, 30+125 Watt loads, 132-174 MHz

- Dual stage isolator with 30+125 Watt load provides 75 dB (typ) isolation
- · Can be tuned over the 132-174 MHz band and comes with built-in harmonic filters
- Compact design shipped precisely tuned to customer specified frequency

Sinclair's PC series panels incorporate high performance single- or dual-stage isolators with various load terminations and Sinclair-built harmonic filters. These compact units offer optimum intermodulation control in a 19-inch rack mounted configuration. They are shipped precisely tuned to customer specified frequency, and exhibit 25 dB or 50 dB isolation when equipped with single- or dual-stage isolators respectively. Various load configurations are available depending on system power level and VSWR protection required.



Region	United States	Europe, Middle East and Africa	Caribbean and Latin America	Canada and rest of the world
Telephone	USA: 1 800 263 3275	International: +44 (0) 1487 84 28 19	International: +1 905 726 7676	Canada: 1 800 263 3275 International: +1 905 727 0165
E-mail	salesusa@sinctech.com	salesuk@sinctech.com	salesla@sinctech.com	salescan@sinctech.com
Product Specification Sheet EPR 018878		PC2214	Issue: 2	Dated: 10-05-16 Dated: 31-08-15
Customer Tech Manual 006641		Sinclair's commitment to product leadership may result in improvement or change to this product		

clair's commitment to product leadership may result in improvement or change to this product Copyright © Sinclair Technologies



MHz	132 to 174	
MHz	5	
	1.25:1	
dB	75	
W	125	
	N-Female	
dB	0.7	
dB	1	
dB	50	
	MHz dB W dB dB dB	MHz 5   1.25:1    dB 75   W 125   N-Female   dB 0.7   dB 1

## **Mechanical Specifications**

Width	in (mm)	19 (483)	
Depth	in (mm)	9.13 (232)	
Length/ Height	in (mm)	3.5 (89)	
Actual shipping weight	lbs (kg)	20 (9.08)	
Shipping dimensions	in (mm)	19x26x7 (483x660x178)	

## **Environmental Specifications**

Temperature range	°F (°C)	-22 to +140 (-30 to +60)	

Region	United States	Europe, Middle East and Africa	Caribbean and Latin America	Canada and rest of the world
Telephone	USA: 1 800 263 3275	International: +44 (0) 1487 84 28 19	International: +1 905 726 7676	Canada: 1 800 263 3275 International: +1 905 727 0165
E-mail	salesusa@sinctech.com	salesuk@sinctech.com	salesla@sinctech.com	salescan@sinctech.com
Product Specification Sheet EPR 018878 Customer Tech Manual 006641		PC2214	Issue: 2	Dated: 10-05-16 Dated: 31-08-15
		Sinclair's commitment to product leadership may result in improvement or change to this product		

clair's commitment to product leadership may result in improvement or change to this produc Copyright © Sinclair Technologies